

Fish Bowl Frenzy Marquee Installation

(This replaces Marquee instructions on page 7 of manual)

1. Check to verify all parts.

- A. (1) Large Plexi Marquee w/LED lights and controller
- B. (1) Metal Mounting Plate w/LED strip attached
- C. (2) Metal Mounting Brackets
- D. Bag of Hardware:

At Least: (10) #8-32 keps nuts

(9) #8-32 machine black screws

(9) black washers

(4) #6 x 1/2" wood screws

A.



B.



C.



D.




Enlarged to show detail


Fish Bowl Frenzy Marquee Installation

(This replaces Marquee instructions on page 7 of manual)

2. Mount the 90° short side of metal brackets to the mounting plate using (2) #8 Keps nuts for each bracket. Make sure the 90° long side of each metal mounting bracket faces the LED lights on the metal mounting plate.



3. Position the Plexi Marquee in front of the metal mounting brackets; position and secure the top hole on each side of the marquee to the top hole on the metal mounting brackets using #8 black machine screws with black washers on the front side face of the plexi.



4. Position and secure the marquee to the center hole of the metal mounting plate using #8 black machine screw with a black washer. This will align the other 6 mounting holes making it easier to fasten the Marquee to the metal mounting brackets and mounting plate.



5. When securing the lower left side of the marquee to the metal mounting plate, make sure not to pinch the wires leading to the controller board between the marquee and mounting plate.

Fish Bowl Frenzy Marquee Installation

(This replaces Marquee instructions on page 7 of manual)

6. Place the fully assembled Marquee on top of your Fish Bowl Frenzy cabinet. Position it toward the front of the machine; make sure that the wire leads coming from the top of your Fish Bowl Frenzy cabinet reach the connectors on the Marquee.



7. Secure the assembled Marquee using the (4) #6 x 1/2" Wood screws. There are 4 holes through the metal mounting plate (2 positioned between the LED light strip and Plexi Marquee and 2 positioned behind the Plexi Marquee).



8. Connect the 2 wire lead from the Fish Bowl Frenzy main cabinet to the LED controller board.
Connect the 2 wire lead from the Fish Bowl Frenzy main cabinet to the LED light strip.

